








ROCK

TWS EARBUDS

WIRELESS BUDS + MAGNETIC CHARGING CASE MANUAL



IMPORTANT SAFETY PRECAUTIONS:

When using your Rock wireless earbuds & charging case, basic safety precautions should always be followed: Read all the instructions before first use, keep these instructions in a safe place for future reference. Ensure when using these earbuds in any activity to always be aware of your environment such as other people, vehicles and animals. Do not use the product near water and do not put on wet surfaces. To clean use a dry clean cloth. Do not allow children to use this product, this is not a toy and this product contains small parts that can present a choking hazard. Parental supervision is advised. Do not expose this product to excessive heat or fire and do not leave in direct sunlight in case of overheating. Do not expose this product to temperatures above 100°F. Do not attempt to repair this product yourself, contact a qualified service centre if you need to service this product. Do not drop, crush or expose this product to physical force. This product is not intended for commercial use. Please recycle or dispose of this product at its end of life, dispose or responsibly based on your local authorities rules. Contact your local recycling centre of how to dispose of safely as this item does contain a battery.

ROCK

Brandquest UK Ltd
Middlewich, Cheshire, CW10 0GF.

One year warranty:
This covers the original purchaser and is not transferable. This warranty covers NORMAL USE, due to defects in materials or workmanship, your product will be repaired or replaced with one year from purchase. Damages or malfunctions resulting from misuse, tampering, modification and accidents are not covered.