


ROCK

ENGLISH


WIRELESS HEADPHONES INSTRUCTION MANUAL

IN THE BOX:



FUNCTIONS ON HEADPHONE

- ① Power ON/OFF and Call Answer
- ② + Track/+ Volume
- ③ Play/Pause
- ④ -Track/- Volume, FM Stations
- ⑤ Mode/Function (BT, TF, FM modes)



EXTRA SPECIFICATION

- All day audio provides around 14hrs playback on a single charge
- Compatible with Apple & Android devices
- Comfort fit ear pieces
- On-ear button controls
- 10m range
- Bluetooth V5.3 for better connectivity
- Call answering enabled
- Adjustable and folding design
- 0-100% charge in around 120 mins*
- 3.5mm Aux port
- 40mm driver units provides superior audio quality delivering crystal clear sound.

HOW TO USE - Follow numbers on diagram for functions.

- ① **Turning Headphones On/Off**
To turn ON or OFF press and hold the 'Power Button'.
ON: The LED will flash blue & green, then the headphones will be ready to pair with your device.
OFF: The LED will not be visible.

- ② **BT Mode - Call Answering**
ANSWER OR END A CALL: Quickly press the 'Power Button'.
REFUSE A CALL: Hold and press the 'Power Button'.

- ③ **TF Mode - Audio Loop**
Double press the 'Power Button' when in TF mode and this will turn looped audio On or Off.

- ④ **Forward Track** - Quickly press '+Track/+Volume' button when in BT/TF mode.
Volume Up - Hold and press '+Track/+Volume' button when in BT/TF mode.
FM Stations - To find stored FM stations quickly press the '+Track/+Volume' button when in FM mode, hold and press the button to turn up the volume.


- ⑤ **Play/Pause** - Quickly press 'Play/Pause' button when in BT/TF mode.
FM Stations Search - Hold and press the 'Play/Pause' button when in FM mode to search for FM stations.

- ④ **Previous Track** - Quickly press '-Track/-Volume' button when in BT/TF mode.
Volume Down - Hold and press '-Track/-Volume' button when in BT/TF mode.
FM Stations - To find stored FM stations quickly press the '-Track/-Volume' button when in FM mode.

- ⑤ **Switch Modes** - Quickly press the 'Mode' button to switch between BT/TF/FM mode.
TF mode can only function if a TF card has been inserted into the headphone.

HEADPHONE PORTS/INPUTS

- ⑥ DC/AUX port
- ⑦ Charging port
- ⑧ TF Card Slot




AUDIO VIA THE AUX CABLE



NOTE: When connected to your device via the AUX cable you will not be able to use the function buttons on the headphones, instead use the controls on your mobile device. (When the AUX cable is connected the microphone on the headphones is disabled).

CHARGING



Red LED ON	Charging
Red LED OFF	Fully Charged

NOTE: Fully charge your headphones before first use. Use the included cable to charge your headphones, connect the cable to a charger, computer or power bank (devices not included). Once charged safely disconnect. A full charge will take around 120 minutes.

SPECIFICATIONS

Bluetooth version	5.3
Connecting distance	≤10M
Battery	300mAh
Charging time	2-3h
Speaker size	40mm
Frequency range	20Hz-20kHz
Impedance	32±15%
Max Power	30mW

* Duration of playback/charge may vary due to volume. Times provided are based at 50% volume.

NOTE: Specifications and images are subject to change without notice.



RoHS

UK
CA

IMPORTANT SAFETY PRECAUTIONS:

When using your Rock wireless headphones, basic safety precautions should always be followed:
Read all the instructions before first use, keep these instructions in a safe place for future reference, use original cables to charge and play your music. Ensure when using these headphones for any activity to always be aware of your environment such as other people, vehicles and animals. Do not use the product in humid areas or near water and do not put on wet surfaces, this product is not waterproof. To clean use a dry clean cloth, do not use any chemicals or detergent. Do not allow children to use this product, this is not a toy as this product contains small parts that can present a choking hazard. Parental supervision is advised as children's hearing is sensitive and their hearing can be damaged with prolonged loud noises. Do not expose this product to low temperatures or excessive heat or fire; do not leave in direct sunlight in case of overheating. Do not expose this product to temperatures above 100°F. Do not attempt to repair this product yourself, contact a qualified service centre if you need to service this product. Do not drop, crush or expose this product to physical force. This product is not intended for commercial use. Please recycle or dispose of this product at its end of life, dispose of responsibly based on your local authorities rules. Contact your local recycling centre of how to dispose of safely as this item does contain a battery. Ensure to check volumes at all times, avoid excessively loud audio as this may damage your hearing.

One year warranty: This covers the original purchaser and is not transferable. This warranty covers NORMAL USE, due to defects in materials or workmanship, your product will be repaired or replaced within one year from purchase. Damages or malfunctions resulting from misuse, tampering, modification and accidents are not covered.



TROUBLESHOOTING

Problems pairing your device via Bluetooth

- 1 - Turn off both your headphones and mobile device, then restart both then follow the steps to pair again.
- 2 - There maybe a conflict with other Bluetooth devices, turn off all local Bluetooth devices.

Distortion in sound or quite audio

- 1 - Check that you headphone battery is not low, recharge fully.
- 2 - Turn up the volume on your mobile device.

Intermittent sound

- 1 - Check you are within 10m range of your mobile device
- 2 - Check there are no obstacles/barriers between the headphones and your mobile device.

Headphone has frozen

Press and hold the ON/OFF button for 10 seconds, this will reset the headphones.

ROCKBT BATCH: 07/23

ROCK

Brandquest UK Ltd
Middlewich, Cheshire, CW10 0GF.
Designed in the UK.
Product made in China.
Design & specification may be subject to change without prior notice.

SCAN
ME
FOR MORE
ROCK



ROCK

WIRELESS HEADPHONES

INSTRUCTION MANUAL

